


SEK (Factory Fit) Setup & operation

keyliteroofwindows.com/fitting-instructions

П

IMPORTANT INFORMATION


- 24 V DC do not connect to mains supply.
- When extending motor cable to wall switch (A), only extend the white and brown cores.
- The installation of this system must be carried out by a qualified electrician the guarantee will be voided if this is not followed.







SEK *Setup*

keyliteroofwindows.com/fitting-instructions












SEK


Setup

keyliteroofwindows.com/fitting-instructions











SEK *Operation*

keyliteroofwindows.com/fitting-instructions

H

